

CHEMICAL RECOVERY

Recovery methods in this category may include surfactant, polymer and alkaline flooding. A reservoir is usually conditioned by a water preflush, then specific chemicals are injected to reduce interfacial tension (help release oil), and/or improve mobility control (reduce channeling and/or viscous fingering). This action is followed by injecting a driving fluid (water) to move the chemicals and resulting oil bank to production wells.

