
# **Mercury Control Program Review**



# The PCO Process for Removal of Mercury from Flue Gas

Christopher R. McLarnon, Evan J. Granite, and Henry W. Pennline

**July 13, 2005** 

**National Energy Technology Laboratory** 





#### **GP-254 / PCO Process**

- Alternative to ACI Developed
- Oxidation of Mercury
- Irradiation of Flue Gas with 254-nm Light
- 90% Oxidation Attained at Bench-Scale
- Low Parasitic Power (less than 0.5%)
- Patent Issued June 2003
- Licensed for Application to Coal-Burning Power Plants (Powerspan Corporation)
- Potential Application for Incinerators

# **Regulatory Drivers**

- EPA Announcement March 15, 2005
- Clean Air Mercury Rule
- Several States Requiring Stricter Reductions
- 70-90% Removal Requirement
- Phased in Over Several Years





# **Fossil Energy Program Goals**

#### **Develop more effective mercury control options**

- Cost-effective and high level of mercury removal
- Meet long-term IEP program goal of 90% mercury reduction at cost reduction of 25-50%
- Must be better than ACI





# Technical Challenges Mercury is Difficult to Capture

- Low concentration
- Exists as Hg<sup>0</sup>
- Harsh conditions of coalderived flue gas
- Competitive adsorption / poisoning
- Low sorbent reactivity
- Hg is semi-noble metal






### **ACI for Mercury Removal**

- Benchmark technology
  - -Deficiencies for flue gas applications
- General adsorbent
- Limited temperature range
- Sequestration
- High sorbent / Hg ratio (3,000:1 to 100,000:1)
- Contacting methods
- Expensive: \$1,000 3,000/ton
- 500 MW<sub>e</sub> power plant: \$0.5 10 MM/yr



# Technical Challenges Mercury is Difficult to Measure

- Low concentration & harsh conditions
- Exists as Hg, HgCl<sub>2</sub>, and Hg<sub>(particulate)</sub>
- Continuous conversion among three
- Broad-band absorbers
- Quenching
- Photosensitized oxidation
- Competitive adsorption/ poisoning





# Background: GP-254 Process Discovery

- Sorbent development
- UV measurement of mercury
- AFS
- Unwanted red-brown stains
- Mercuric oxide
- Serendipity



### **Photochemical Oxidation of Mercury**

- Mercury can absorb and emit 253.7 nm light
- Atomic Absorption (AAS)

Hg + 253.7 nm radiation 
$$\rightarrow$$
 Hg\* Hg 6 ( $^{3}P_{1}$ ) (I)

Atomic Emission (AES)

$$Hg^* \rightarrow Hg + 253.7 \text{ nm radiation}$$
 (II)

- Atomic Fluorescence (AFS): steps (I) and (II)
- Basis for CEMs



### What Is Quenching?

- Intensity of fluorescent emission diminished
- Energy transfer due to collisions
- Function of size, shape, and reactivity
- Primed for chemical reaction (activation)
- Interferes with ultraviolet spectroscopy

Hg + 253.7 nm light 
$$\rightarrow$$
 Hg\* Hg 6 ( $^{3}P_{1}$ )
Hg\*  $\rightarrow$  Hg + 253.7 nm light Fluorescence
Hg\* + M  $\rightarrow$  Hg + M\* Quenching



## **Quenching Cross Sections**

$$Hg 6(^{3}P_{1}) + M \rightarrow Hg 6(^{1}S_{0}) + M^{*}$$

#### **Function Of Size, Shape And Reactivity**

Species Cross Section (cm<sup>2</sup>)

HCI  $37.0 \times 10^{-16}$ 

NO  $24.7 \times 10^{-16}$ 

 $O_2$  13.9 x  $10^{-16}$ 

CO  $4.1 \times 10^{-16}$ 

CO<sub>2</sub> 2.5 x 10<sup>-16</sup>

 $H_2O$  1.0 x  $10^{-16}$ 

 $N_2$  0.4 x 10<sup>-16</sup>



#### **Photochemical Oxidations**

- First described in 1926 by Dickinson & Sherrill (O<sub>2</sub>)
- Gunning discovered others in 1950s (HCI, H<sub>2</sub>O, CO<sub>2</sub>)


#### **Relevant Overall Reactions**

Hg + 2 
$$O_2$$
 + 253.7 nm light  $\rightarrow$  HgO +  $O_3$   
Hg + HCl + 253.7 nm light  $\rightarrow$  HgCl + 1/2 H<sub>2</sub>  
Hg + H<sub>2</sub>O + 253.7 nm light  $\rightarrow$  HgO + H<sub>2</sub>  
Hg + NO<sub>2</sub> + 253.7 nm light  $\rightarrow$  HgO + NO  
Hg + CO<sub>2</sub> + 253.7 nm light  $\rightarrow$  HgO + CO

- Interferes with UV-based CEMs
- Potential removal method




#### **Lab-Scale Photoreactor**











### **Experimental Parameters**

- Quartz Photoreactor, 6-watt UV lamp
- Temperatures: 80°F, 280°F, 350°F
- Flow-rate: 60 ml/min Reaction time: 350 min
- Intensity: 1.4 mW/cm²

#### **Gas Compositions**

A: 16% CO<sub>2</sub>, 5% O<sub>2</sub>, 2000 ppm SO<sub>2</sub>, 300 ppb Hg, balance N<sub>2</sub>

B: 16% CO<sub>2</sub>, 5% O<sub>2</sub>, 2000 ppm SO<sub>2</sub>, 500 ppm NO, 300 ppb Hg, balance N<sub>2</sub>



#### **Results: Photochemical Removal**

<u>Gas</u>	Temp (°F)	Mean Hg Capture (%)
Α	350	$2.3 \pm 2.0$
Α	280	71.6 ± 30.1
Α	80	$67.8 \pm 28.8$
В	280	26.8 ± 11.7

- Removal as mercuric oxide/mercurous sulfate stain
- Higher removals below 300°F
- Limited by thermal decomposition of O<sub>3</sub> (300-350°F)
- NO reduces removal, possibly by consuming ozone
- Low energy consumption
- Potentially low operating costs

#### **Conclusions: Photochemical Oxidation**

#### **Method For Mercury Removal**

- Obvious interference For CEMs
- High levels of mercury removal from SFG
- Capture as HgO and Hg<sub>2</sub>SO<sub>4</sub>
- Enhanced removal below 300°F



#### **Conclusions: Photochemical Oxidation**

#### **Potential For Better Performance**

- Other oxidants (HCl, H<sub>2</sub>O, NO<sub>2</sub>) in flue gas
- Promising process economics
- Potential for multi-pollutant control
- Pilot-scale data needed
- Low rank coals are of particular interest




# Larger Scale Testing Bench-Scale Photoreactor

- Slipstream of flue gas from 500-lb/hr pilot
- Temperature: 280°F 350°F
- Effect of temperature, radiation intensity residence time & composition
- Removals measured on-line by CEM
- Impact upon other flue gas species
- Determine GP-254 process economics



#### NETL BENCH-SCALE PHOTOREACTOR








#### **NETL Bench-Scale Photoreactor**

- ½-inch by 33-inch Quartz Tube
- Two 30-W Low Pressure Mercury Lamps
- 254-nm Intensity: 20 mw/cm²
- Gas Composition: PRB Flue Gas
- Temperature: 120°F 280°F
- Flow-Rate: 8 liters/min
- Sir Galahad CEM Monitor Inlet/Outlet Mercury







#### **NETL Bench-Scale Results**

# **Significant Level of Mercury Oxidation**

- Slipstream of Particulate-Free PRB Flue Gas
- 6 50 μg/Nm³ Elemental Mercury (Spiking)
- Low Power Consumption
- Typically 30-70% Removal of Mercury
- Extremely Low UV Intensity Applied
- Non-Optimized Bench-Scale Apparatus



# **Powerspan Bench-Scale Results**

# **Commercial Lamp System**

- Flow-rate: 24 scfm
- Temperature: 120 140°F
- Intensity: 13.8 W/cm<sup>2</sup> -- Low Parasitic Power
- Mercury Concentration: 13.0 μg/Nm<sup>3</sup>
- 5.6% O<sub>2</sub>, 13% CO<sub>2</sub>, 8% H<sub>2</sub>O, 1300 ppm SO<sub>2</sub>,
   220 ppm NO, 20 ppm CO, and balance N<sub>2</sub>
- 91% Removal
- Pilot-Scale Tests in 2005

