

Fourth Annual Conference on Carbon Capture & Sequestration

*Developing Potential Paths Forward Based on the
Knowledge, Science and Experience to Date*

Capture and Separation – Sorbents 1

Pilot Plant Testing of Aqueous Piperazine and Potassium Carbonate for CO₂ Capture

Eric Chen, Gary Rochelle, Frank Seibert

May 2-5, 2005, Hilton Alexandria Mark Center, Alexandria Virginia




Outline

- Advantages of K_2CO_3 /Piperazine
- Objectives of Scale-up
- Pilot Plant with 16.8-inch Contactors
- Comparison of Bench and Pilot Results
- Conclusions




K_2CO_3 Promoted by Piperazine (PZ)

- New Solvent Developed by Cullinane (2005)
 - 2.5 m PZ / 2.5 m K_2CO_3
 - CO_2 Absorption 1.5 – 3 Times Faster than 30 wt% MEA
 - Heat of Absorption 10-25% Less than MEA
 - Implications
 - 1.5-2.5 less Packing and Pressure Drop
- OR
- Closer Approach to Saturation - 10-20% Less Energy


Wetted Wall Column



CO₂ Absorption by K⁺/Piperazine



Wetted Wall Data at 60°C



Research Objectives


- Develop & Validate Design Methods for Scaleup from Bench-scale Measurements
 - CO₂ Absorption in Potassium Carbonate Promoted by Piperazine
 - Wetted Wall Column & Absorber Pilot Data
- Characterize & Understand T Bulges
- Demonstrate Reliable Operation of System
- Target Application – Coal-Fired Power Plants

CO₂ Pilot Absorber/Stripper System

- Pickle Research Center
- Column ID – 16.8 in
- Packed Height – 20 ft in 2 Beds (10 ft Each)
- Collector Plate & Redistributor in Between Packed Beds
- Multi-use facility (distillation/extraction)



Pilot Plant Schematic



Campaign 2 Summary

Absorber Packing	Flexipac 1Y
Stripper Packing	IMTP #40
K ₂ CO ₃ Conc. (wt%)	22
K ⁺ /PZ	2
Inlet CO ₂ (%)	2.6 – 12.6
CO ₂ Removal (%)	60 – 97.5
Lean Ldg (mol CO ₂ /K+2PZ)	0.4 – 0.49
P _{STRIPPER} (atm)	0.3 – 1.8


Absorber Rate Data Analysis

$$K_G = \left(\frac{G}{a_{eff}} \right) \frac{\ln \left[\frac{CO_{2,IN} - CO_{2,IN}^*}{CO_{2,OUT} - CO_{2,OUT}^*} \right]}{\frac{\left((CO_{2,IN} - CO_{2,IN}^*) - (CO_{2,OUT} - CO_{2,OUT}^*) \right)}{(CO_{2,IN} - CO_{2,OUT})}}$$


- G = Inlet Gas Rate
- a_{eff} = Correlated Effective Area from KOH Data
- Calculate $P_{CO_2}^*$ from Model Fitted to Bench-scale VLE Data
- Calculated K_G for Top, Bottom and Overall Bed
- Validated Bench-scale VLE with Pinch Points in Absorber
- Plot K_G against Average Loading Across Bed(s)

Absorber Temperature Profiles


8 – 12.4% Inlet CO_2



VLE Pinch Analysis



Mass Transfer Results



Stripper Operation at 1.6 atm

Reboiler T – Rich Solvent T (°C)	38 – 52
Top T (°C)	83 – 113
Bottom T (°C)	117 – 122
Reboiler Heat Duty (kcal/mol CO ₂)	107 – 177

- Inadequate Preheat of Stripper Feed
- New Cross-Exchanger in Next Campaign

Conclusions

- Matched VLE from Bench-scale Data
- CO₂ Absorption Rates are 1.5 – 3 Times Higher than Bench-scale
- Average Top and Bottom K_G Approximately Matched Bench-scale Data
- Temperature Bulge Varied from 18 to 33 °C with High CO₂

Acknowledgements

- U.S. Department of Energy (DE-FC26-02NT41440)*
- EPA STAR Fellowship
- Industrial Associates Program for CO₂ Capture
- UT College of Engineering
- UT Separations Research Program
- Koch-Glitsch Inc.
- Emerson Process/Rosemount Analytical
- CD Tech
- Dyzack / DOE
- Huntsman Corporation

* This work was supported by DOE Cooperative Agreement DE-FC26-02NT41440, by an EPA Star Fellowship, by the Separations Research Program at the University of Texas, and by the a number of industrial sponsors. However, any opinions, findings, conclusions, or recommendations expressed herein are those of the authors and do not necessarily reflect the views of the DOE or other sponsors.

Questions?

