

Fifth Annual Conference on Carbon Capture & Sequestration

Steps Toward Deployment

Ocean Sequestration


Scale-up of CO₂ Hydrate Particle Formation for Ocean Carbon Sequestration

P. Szymcek, C. Tsouris, S.D. McCallum, P. Taboada-Serrano, and J. Gabitto
Oak Ridge National Laboratory

E.E. Adams, and A.C. Chow
MIT Dept of Civil and Environmental Engineering

P.G. Brewer, E.T. Peltzer, and P. Walz
Monterey Bay Aquarium Research Institute



May 8-11, 2006 • Hilton Alexandria Mark Center • Alexandria, Virginia



Marine Injection of CO₂: Background

- Marine sequestration of CO₂ is a possible method to counteract the increase in atmospheric CO₂.
- Costs of methods increase with injection depth. Residence times of sequestered CO₂ increase with increasing depth.
- Using hydrate formation to sequester CO₂ will decrease costs by decreasing depth necessary for injection.

Concept of CO₂ Hydrate for Ocean Sequestration



- The density of the composite produced depends highly on the conversion of liquid CO₂ to hydrate.

Objective of this Part of CO₂ Hydrate Injection

- Previous field and laboratory studies demonstrated the concept of injecting CO₂ hydrate particles at a shallow depth for ocean sequestration.
- The objective of this research is to test a larger-scale continuous-jet hydrate reactor.
- This reactor increases CO₂ flowrate by approximately two orders of magnitude.

Methods Used in Laboratory at ORNL

The ORNL SPS (Seafloor Process Simulator)

- 72 L Volume
- Hastelloy
- Pressures up to 20 MPa
- Temperatures 0°C and up
- 41 sampling ports




The ORNL Continuous-jet Hydrate Reactor





The Continuous-Jet Hydrate Reactor: Geometry and Conditions II

Injector side-view



Capillary plan-view



The Continuous-Jet Hydrate Reactor: Geometry and Conditions I

- This reactor allows different capillary sizes to be used.
 - Single-capillary: 2.381-mm, 3.175-mm, and 3.969-mm
 - Multiple-capillary: 0.379-mm, 0.794-mm, 1.191-mm, and 1.588-mm.
- Variable flow rates for both liquids were tested.
 - Water: between ~0.80 and ~3.00 L/min water
 - CO₂: between ~0.33 and ~0.66 L/min CO₂ (pulsed)
- Pulsed CO₂ flow duration is equivalent to CO₂ ~5.5 L/min.
- Temperatures: 1.5 to 5°C
- Pressures: 4.8 to 13.1 MPa
- Experiments were conducted in both distilled and saline water.

Summary of Parameters Investigated


- Bouyancy
- Pressures and Temperature
- Dispersed v. continuous phases
- Capillary size
- Capillary configuration (multiple or single capillary)
- Water chemistry
- Dissolution rates of produced hydrate

Experimental Results

- Liquid CO₂/water/ CO₂-hydrate consolidated composite particles were successfully produced in the laboratory.
- All capillary sizes and configurations yielded hydrates with varying buoyancies and levels of consolidation.
- Consolidated composites were formed at pressures as low as 4.8 MPa.

Effects of CO₂ v. Water as Dispersed Phase I

- Buoyancy differences were observed between hydrate produced using water or CO₂ as the dispersed phase.
 - Experiments using water as the dispersed phase typically produced floating hydrate.
 - Experiments using CO₂ as the dispersed phase typically produced sinking hydrate.
 - This behavior is due to the pulsed flow of CO₂.



Effects of CO₂ v. Water as Dispersed Phase II

- Clogging problems were not observed during testing of the injector, as apposed to previous experiments with smaller injectors.
- Using water as dispersed phase produced sinking composite only at pressures exceeding 13.1 MPa (~1300 m).
- Using CO₂ as dispersed phase produced composites with greater density.

Effect of Capillary Size I

- Smaller capillary sizes typically produced more consolidated and dense hydrate composite.
- Reynolds Number: $Re = 4\rho Q/\pi d^0 \mu$
 - The ratio of inertial forces to viscous forces.
- Ohnesorge Number: $Z = \mu/(\rho\sigma d^0)^{0.5}$
 - The ratio of viscous forces to surfaces forces.
- This can be attributed to greater Reynolds and Ohnesorge numbers associated with smaller capillary sizes.

Effect of Capillary Size II

Dispersed Phase	Capillary Diameter (mm)	Pmin (MPa)	Temp (°C)
Single Capillary			
Distilled Water	3.175	sinking not observed	4.5
	3.969	sinking not observed	4.5
	Multiple Capillary		
	1.191	13.1	2.5
	1.588	sinking not observed	4.0
Single Capillary			
Liquid CO ₂	2.381	7.6	5.0
	3.175	sinking not observed	4.0
	Multiple Capillary		
	0.397	6.2	4.2
	0.794	6.2	3.5
	1.191	6.9	5.1
	1.588	7.6	3.3

Effect of Capillary Configuration: Multiple or Single-Capillary

- Results from multiple and single-capillary configurations with similar total cross-sectional areas were compared.
- These results indicated that multiple-capillaries produce more dense and consolidated composite. This is probably due to smaller droplet size.

Comparison of Single and Multiple-capillaries with Similar Total Cross-Sectional Area


			Single Capillary			Multiple Capillary		
Pmin	Water Flow	CO ₂ Flow	Temp	Diameter		Temp	Diameter	
MPa	L/min	mL/min	°C	mm	Behavior	°C	Mm	Behavior
11.7	2.00	0.33	4.0	3.175	C NB	4.4	1.191	C S
11.7	2.00	0.40	4.0	3.175	C F	4.4	1.191	C S
11.7	2.00	0.50	4.0	3.175	U F	4.4	1.191	C S
11.7	2.00	0.66	4.0	3.175	U F	4.4	1.191	C S
11.7	2.50	0.33	4.0	3.175	C NB	4.4	1.191	U S
11.7	2.50	0.40	4.2	3.175	C NB	4.4	1.191	C S
11.7	2.50	0.50	4.2	3.175	U NB	4.4	1.191	C S
11.7	2.50	0.66	4.2	3.175	U F	4.4	1.191	C S
11.7	3.00	0.33	4.2	3.175	NB C	4.4	1.191	C S
11.7	3.00	0.66	4.2	3.175	C F	4.4	1.191	C S
10.3	3.00	0.66	3.9	3.175	U F	5.1	1.191	C S

U = Unconsolidated, C = Consolidated, S = Sinking, NB = Neutrally Buoyant, F = Floating

1.191-mm multiple-capillary = 7.795 mm² and 3.175 single-capillary = 7.913 mm²

- Hydrate produced using a multiple-capillary has a greater density than composite produced using a single-capillary of similar total cross-sectional area.

Reynolds and Ohnesorge Numbers for Different Dispersed Phases.



Effect of Water Salinity I

- The scale-up reactor was tested using saline and distilled water.
- The reactor produced negatively buoyant and consolidated hydrate in both saline and distilled water.
- Saline water increases the pressure and decreases temperature necessary to produce sinking hydrates.


Effect of Water Salinity II

Saline Water				Distilled Water			
Pmin	Temp	Water Flow	Behavior	Pmin	Temp	Water Flow	Behavior
MPa	°C	L/min		MPa	°C	L/min	
13.1	1.9	2	C S	4.8	4.2	2	U F
13.1	1.9	3	C S	6.2	4.2	2	U NB
11.7	1.5	2	C S-NB	6.7	4.1	2	C S
11.7	1.6	3	C S	7.6	4.1	2	C S
11.7	3	2	C NB	9	5.2	2	C S
11.7	2	2	C S-NB	10.3	5.1	2	C S
11.7	3.5	2	C F	11.7	4.4	2	C S
13.1	4.7	2	C F	13.1	3.5	2	C S


C = consolidated, F = floating, NB = neutrally buoyant, S = sinking, and U = unconsolidated.
Pmin = minimum pressure required to produce sinking composites. CO₂ flowrates all at 0.66 L/min

- Increasing water salinity lowered temperature and increased pressure necessary for producing sinking composite.

CO₂ Hydrate Dissolves as it Descends in Seawater



Mass-transfer modeling
based on single particle



Additional effects occur in a plume
allowing the particles to descend
for as much as 1000 m before
dissolution:

- Solute density effect: Seawater density increases due to CO₂ dissolution
- Plume effect: Particles sink with plume velocity plus settling velocity

Riesterberg et al., ES&T, 2005


Summary

- A scaled up continuous-jet hydrate reactor was successfully developed and used to form hydrate composite particles.
- Optimum operation conditions at intermediate ocean depths for the continuous-jet hydrate reactor were determined.
- Ideal conditions for producing negatively buoyant composites include the use of a multiple-capillaries, pulsed CO₂ flow, temperatures of 2.0-3.0°C, and pressures ~ 11.7 MPa.

Acknowledgment

Ocean Carbon Sequestration Program, OBER
(U.S. DOE, grant no. KP120203)

Ongoing Research



Ongoing Research

