

# **Multiplexed Sensor for Synthesis Gas Composition and Temperature**

**DOE University Coal Research Project**

**Initiated September 2004**

**DOE Grant #DE-FG26-04NT42172**

**Steven G. Buckley, Reza Gharavi, Marco Leon, and  
Ariel Schuger**

**Department of Mechanical and Aerospace Engineering  
University of California, San Diego**


**Contractors Meeting June 6-7, 2006**

# Outline of talk

- **Introduction and motivation**
- **Abbreviated description of the sensing technique**
- **Sensor design**
- **Development of new spectroscopy**
- **Progress on measurements**
- **Upcoming work**

# The promise of gasification

- “Baseline” coal plants are ~ 33-35% thermal efficiency
- Integrated combined-cycle plants may exceed 50% thermal efficiency
- May aid in CO<sub>2</sub> sequestration
- Fischer-Tropsch fuels from syngas



## The goals of this project

- Integrated high-speed sensor that can measure composition of important major and minor species in real time and *in situ*.
- Targeted species:  $\text{CH}_4$ ,  $\text{H}_2\text{O}$ ,  $\text{CO}$ ,  $\text{CO}_2$ ,  $\text{NH}_3$ ,  $\text{H}_2\text{S}$

### → Challenges

- High, variable temperature
- High, variable pressure
- Sensitivity with short pathlength
- Rugged design

## **Benefits to tunable diode laser approach**

- **Near-infrared tunable diode lasers have been developed by large telecommunications investment**
  - Relatively inexpensive hardware
  - Durable hardware
- **Direct optical measurements are obtained in real-time without perturbations to concentrations that might occur in a sampling system**
- **Measurements can easily be performed at several hundred Hz**
- **Laser light can be multiplexed and fiber-coupled**
- **Multiple species can be simultaneously measured with one detection system**

# Familiar ground: Absorption spectroscopy

- **Beer's law** 
$$\frac{dI(\bar{\nu})}{I_0(\bar{\nu})} = -k(\bar{\nu}) \cdot C \cdot dx$$

- **Concentration measurements**




- Integrated absorption of spectral line

$$\bar{A} = \int_{line} k(\bar{\nu}) CL d\bar{\nu} = \bar{k} CL$$


- Calibration

$$C_{sample} = \frac{\bar{A}_{sample}}{\bar{A}_{calibration}} \cdot C_{calibration} \cdot r_{path}$$

# Theory of absorption spectroscopy



# Key: Wavelength Modulation Spectroscopy (WMS)




**Problem:** difficulty in detecting a small dip in a large signal, particularly with a fluctuating background

- **Attributes of WMS**
  - Increases sensitivity by 2-3 orders of magnitude
  - Eliminates most flow-related sources of noise
  - Allows frequency-domain multiplexing and demodulation




# Direct absorption vs. “Wavelength modulation”

Typical absorption line shape



Function of collisional and Doppler broadening  
(Lorentzian shape) + (Gaussian shape)

Direct absorption



50 - 1000 Hz sweep  
of laser current

$$I / I_0 = \exp(-S_T g(\nu - \nu_0) L P_{\text{abs}})$$

Beer's law absorption

**Problem: measurement of small signal  
on large background**

Wavelength modulation



50 - 1000 Hz sweep  
of laser current


+





kHz rates modulation

- Modulation rejects flow-related noise, electrical noise, etc., typically  $1/f$
- Detection of  $1f$ ,  $2f$ , etc. signals with lock-in amplifier





# How WMS works




- **Harmonic signals look like derivatives of the absorption line, hence sometimes called “derivative spectroscopy”**



# Comparison of direct absorption, 2f, 3f, and 4f signals of 200 torr CO<sub>2</sub>




# How is the signal processed?




# Experiments measure the temperature and pressure broadening characteristics of each absorption line

- Schematic of the experimental apparatus for line strength and pressure broadening measurements (at different temperatures) is shown below




# Example: Line strength measurements as a function of temperature

- Measurements of R(4) CH<sub>4</sub> transition are fit to model to derive line strengths as a function of temperature





# Example: Line strength measurements as a function of temperature

- Measured individual line strengths of CH<sub>4</sub> R(4) manifold at T=296 K (Should be pressure-independent)



# Example: Pressure broadening measurement for CH<sub>4</sub> transitions


- Each gas component in the mixture contributes independently to line broadening – must be measured






# WMS at high pressure: Line-locked measurements

- Increased broadening dramatically increases line width at high pressures
- Most near-infrared TDLs only tune 1-2  $\text{cm}^{-1}$



- Solution – eliminate the “sweep” signal, only modulate the laser about the line center
- ➔ Relies on having very accurate models of the line for interpretation of the signal

# TDL-based temperature measurements




**Schematic variation of line strength of two absorption lines with temperature**


$$R_{abs}(T) = \frac{S_i(T)}{S_j(T)}$$

# TDL H<sub>2</sub>O / Temperature measurement

Measured absorbance of selected H<sub>2</sub>O transitions (near 1478 nm)  
at two different temperatures





At T1=468 K



At T2=997 K



# TDL H<sub>2</sub>O / Temperature measurement

Measured absorption line strengths of the selected H<sub>2</sub>O transitions vs. temperature




# TDL H<sub>2</sub>O / Temperature measurement

## Variation of absorption ratio vs. temperature



- Accurate models of spectral lines are crucial for variable conditions

# Overall sensor architecture




All accomplished  
in Labview™

# Progress to date in sensor development

- **H<sub>2</sub>O, CH<sub>4</sub>, CO, and CO<sub>2</sub> spectroscopy are completed**
  - A new long-pathlength, high-pressure cell was constructed for these measurements
  - We have complete pressure broadening and temperature data for these species
- **NH<sub>3</sub> and H<sub>2</sub>S are in progress**
  - Lasers have been received, lines have been selected
  - Initial spectra have been acquired, characterization of pressure broadening and temperature data is proceeding
  - Difficulty with toxicity of species, and complexity of spectra
    - A cell and flow system for these toxic gases has been constructed

## Completed hardware





- Long path, high-temperature cell allows more sensitive measurements
- High-pressure cell (not shown) is used to investigate agreement of model and experiment at high pressure
- Electronics box controls multiple lasers






# “Difficult” ammonia spectra measured in the lab




- **Very complicated**
  - Many peaks
  - Databases are incomplete / incorrect
- **In the lab, cannot test at high temperature with  $\text{H}_2\text{O}$  present**
  - Constructed multiple-path experiment
- **Top = low pressure, Bottom = atmospheric pressure**

# We have constructed a model for $\text{NH}_3$ spectra



- Upper trace  $\rightarrow$  total spectra, predicted versus modeled
- Lower trace  $\rightarrow$  individual modeled lines
- For quantification, it was necessary to model 21 individual lines
- Model particularly useful for pressure-broadened measurements
- Time-consuming to construct
- Similar effort underway for  $\text{H}_2\text{S}$



## **Progress to date: Design and construction**


- **National Instruments' PXI system and ILX Lightwave temperature controller / diode driver have been integrated into system**
- **Two electronics boxes have been designed, built, and tested**
  - a modulation box that takes a single sweep input and superimposes 4 modulation signals of fixed frequency and variable amplitude
  - a reference box that normalizes the detector signal by the input laser power to correct for fluctuations and nonlinearities in the laser signal
- **Hardware is essentially in final form**

# Advanced Labview™ software built and tested

Control of  
laser  
parameters

Control of  
graphical  
output

Ability to  
save spectra




1<sup>st</sup> harmonic  
(column)

2<sup>nd</sup> harmonic  
(column)


Four  
channels  
showing  
H<sub>2</sub>O, CO<sub>2</sub>,  
CH<sub>4</sub>, and  
CO spectra



# Entire assembly in the lab



# System allows simultaneous recording of multiple real-time spectra on a single detector



## Field Trials: September 2005 and April, 2006

- The UCSD campus (~23,000 students, 1,200 acres) generates most of its own power using 2 Solar Turbines Titan 130, 13 MW gas turbines
- Internal funding supported real-time measurements on the turbines for emissions monitoring and oscillation detection
- CO<sub>2</sub>, H<sub>2</sub>O, and temperature were monitored



## Key results

➔ Each of these was a “projected milestone” last year

- $\text{H}_2\text{O}$ , temperature,  $\text{CO}$ ,  $\text{CO}_2$  and  $\text{CH}_4$  have been simultaneously measured and quantified at high temperature using collisional broadening and line strengths measured in the laboratory
- $\text{NH}_3$  and  $\text{H}_2\text{S}$  spectra have been obtained, measurements of parameters and modeling are both proceeding
- Architecture is finished and tested
- Labview™ lock-in program coupled with data acquisition system has been successfully tested
- On-campus field trials have been helpful to eliminate errors in system and improve software



## Upcoming milestones

- **Finish  $\text{NH}_3$  and  $\text{H}_2\text{S}$  spectroscopy**
- **Add calibration to software so that reporting can be in “real units”**
- **Final – measurements on an operating gasifier**

# Summary and Conclusions

- **Project is making substantial progress with respect to research and development goals**
- **Hardware development and spectroscopy development have been mostly completed**
  - $\text{CH}_4$ ,  $\text{H}_2\text{O}$ ,  $\text{CO}$ ,  $\text{CO}_2$  spectroscopy all finished
  - Labview™ software replaced substantial hardware, adds versatility
  - Extra time was required for  $\text{NH}_3$  and  $\text{H}_2\text{S}$ , beyond proposal estimates
- **Second field trial appears to have been successful**
  - Quantification in process
  - Calibration will be incorporated into software
- **Final goal: test on an operating gasifier**
  - Have been in touch with Dr. Tom Gale at the Southern Company gasifier about the potential for measurements there

# Selected recent and in-preparation papers

- M. Gharavi and S.G. Buckley, “Diode Laser Absorption Spectroscopy Measurement of Line Strengths and Pressure Broadening Coefficients of the Methane  $2\nu_3$  Band at Elevated Temperatures,” *Journal of Molecular Spectroscopy* 229 pp 78-88 (2005).
- M. Gharavi and S.G. Buckley, “Near-infrared optical sensor for monitoring  $\text{NH}_3$ ,” to be presented, **FACSS** 2006.
- M. Gharavi and S.G. Buckley, “Pressure broadening parameters of  $\text{H}_2\text{O}$  absorption transitions of  $2\nu_1$  and  $2\nu_2+\nu_3$  bands at elevated temperatures,” *submitted, Journal of Quantitative Spectroscopy & Radiative Transfer*.
- M. Gharavi and S.G. Buckley, “Wavelength modulation spectroscopy for temperature and  $\text{H}_2\text{O}$  concentration measurement using a single diode laser,” *submitted, Applied Optics*.
- M. Gharavi, M. Leon, and S.G. Buckley, “Real-Time Measurement of  $\text{H}_2\text{O}$ , CO, and Temperature in an Operating Gas Turbine,” to be submitted to *Measurement Science and Technology*.
- A. Schuger, M. Gharavi, and S.G. Buckley, “In-Flame, Real-Time Measurement of  $\text{H}_2\text{O}$ , CO, OH, and Temperature,” to be submitted to *Combustion Science and Technology*.
- M. Gharavi, C. Lao, and S.G. Buckley, “Line Strengths and Pressure Broadening of Selected Transitions of CO and  $\text{CO}_2$ ,” to be submitted to *Journal of Molecular Spectroscopy*.



**Thanks for your attention!**

**We appreciate the kind assistance of our  
program manager Robie Lewis and the support  
of DOE on this project**




## Additional slides

# National Instruments data acquisition system

- **PXI system has integrated Windows™-based microprocessor, 6 channels of 500 kHz analog input and 2 channels of analog output**
- **Completely configurable using Labview™ graphical programming language designed for data acquisition**
- **Enough horsepower to do some real-time computations**
- **Rugged and portable**





## Laser selection

- Modeled and experimental spectra are consulted to find best lines in near infrared
- Lines are checked for interferences from H<sub>2</sub>O and other gases
- Laser manufacturers are contacted to determine laser availability