




EERC

Energy & Environmental Research Center

EERC Technology – Putting Research into Practice

Determination of Mercury in Plume at Pleasant Prairie



University of North Dakota

Project Goal

To gain an understanding of mercury chemistry as a plume moves downstream from the stack.

Twin Otter International DHC-6-300 Vistaliner




Major Equipment to Be In Plane

- Tekran Automated Mercury Speciation System
 - Particulate-bound Hg, RGM, Hg⁰
- Data Acquisition (Mercury, NO_x, GPS, Timing sequences)
- NO_x Analyzer modified for faster response time.
- Inverter and Power Supply

Other Sampling And Analytical Equipment

- Heated Probe mounted on the side of the aircraft along with heated sample lines.
- A GPS system to document plume locations
- Valves, Mass Flow Controllers etc.
- In situ measurement of temperature, pressure, and humidity
- Three-dimensional winds and turbulence data.

Ontario Hydro Method Train



Ontario Hydro Method Train





Diagram of the Tekran Automated Hg Analyzer



Plume Sampling

- Annular denuders used to capture RGM
- Hg^0 captured by the Tekran gold trap
- Particulate-bound mercury is captured by a filter then desorbed to the analyzer
- The detection of the plume will be done using a NO_x analyzer

Plume Sampling (cont.)

- Sampling will be done at three locations within the plume
 - As close to the stack as possible
 - At a distance of about 1-2 miles
 - At a distance of 4-5 miles.
- The plane will fly at about 50m/sec so multiple passes will be necessary
- Depending on the plume diameter at any give location sampling will either traverse the plume or be done along its axis.

Stack Sampling

- A Hg SCCEM will be located at the stack measuring mercury continuously during the entire test
- Three Ontario Hydro Samples will be taken at the stack when the Hg SCCEM is set up.
- One additional Ontario Hydro Sample will be taken each flight day.

Contact Information

Energy & Environmental Research Center

University of North Dakota

15 North 23rd Street

PO Box 9018

Grand Forks, North Dakota 58202-9018

World Wide Web: **www.undeerc.org**

Telephone No. (701) 777-5000

Fax No. (701) 777-5181

Dennis Laudal

dlaudal@undeerc.org

(701) 777-5138

Grant Dunham

gdunham@undeerc.org

(701) 777-5034

