

# Measurement of Alpha Contamination on Surfaces using an Electret Ion Chamber (EIC)



HCET-1998-C008

PI: Florida International University

Collaborator: S.K. Dua, Ph.D.

Hemispheric Center for  
Environmental Technology


Florida International University

**FY 1999 DDFA Annual Review Meeting**

**Morgantown, WV May 25-27, 1999**



# Technical Overview




- **Electret Ion Chamber Technology**


- Electret Ion Chamber (EIC)
  - Electret - a charged Teflon disk
  - Ionization chamber
- Electret
  - Collects ions produced by alpha radiation.
  - Surface charge is reduced through collection of ions.
  - Rate of reduction of the surface charge gives a measure of alpha radiation.
  - 3 thicknesses ( 0.013, 0.16, 4.76 mm) commercially available.




# Technical Overview



## Electret, Chamber and Charge Reader




# Field Deployment Scenario



Measurement of Alpha Contamination on Surfaces using an Electret Ion Chamber (EIC)

# Comparison with Baseline Technology



## • **Baseline Technology**

### Alpha Probe and Scaler

- Hand-held alpha monitors: gas flow/filled proportional counters, scintillation counters
- Floor monitors- low sensitivity  
Alpha particles small range (~0.004 cm in tissue/paper)  
detector window- thin, placed close contact with floor
- Wipe test - removable contamination, generates waste

## • **Electret Ion Chamber**


### EIC and Reader

- Passive charge integrating device; for measurement EIC is placed on surface (floor, walls, etc.) and picked up after known exposure time
- Reusable chamber; chamber rim can be decontaminated
- Not affected by puncturing/ damage of thin Mylar window
- Total alpha contamination

## • **Cost savings analysis to be performed in SRS LSDDP**




# FIU-HCET ceramic tile test-bed



Measurement of Alpha Contamination on Surfaces using an Electret Ion Chamber (EIC)

# Test Bed Results - Comparison EIC vs. Alpha Probe




Description of Tiles	Alpha contamination (dpm/ 100cm <sup>2</sup> )	
	EIC	Alpha Probe
White 13" X 13" Décor Vitro Tiles	122.43 ± 13.80	126.27 ± 2.04
Beige Marble 16" X 16" (Prima) Stylnu Tiles	65.88 ± 12.06	59.01 ± 2.05
12" X 12" White Tiles	33.22 ± 7.56	36.98 ± 3.20





# Conclusions



## Comparative study with a baseline technology shows

- EIC more rugged- Mylar window damage, no effect on performance.
- Lowers personnel exposures- 27 hours for 200 measurements.
- Less expensive- saving of \$ 150 M for measurement on concrete surfaces alone.
- Technology is mature for demonstrations (LSDDP- SRS) and deployment (OR).
- Data from LSDDP- SRS in support of DDFA will be used for ITSR.
- Inexpensive large area ceramic tiles test-beds are useful for comparative assessment of alpha measuring techniques and instrument calibration.

