

LOW NO_x CONTINUOUS EMISSIONS MEASUREMENTS FROM GAS TURBINES

**Allan Budd & Tom Baldwin
Baldwin, Inc.**

**2003 Conference on SCR and SNCR
for NO_x Control, Pittsburgh PA
October 30, 2003**

Background

- **CARB Low NOx Committee**
- **UC Riverside CE-CERT Low NOx Study**
- **Dow Chemical Project (Gluck et. al.)**
- **GE NOx Analyzer Study**
- **Horiba Low NOx study (Downey et. al.)**
- **Baldwin Low NOx projects (Budd/Baldwin)**
- **USEPA method update (Harrison et. al.)**

Issues

- **Can a CEMS measure NO_x at 1–10 ppmv in the real world?**
- **Can a CEMS measure NH₃ with sufficient accuracy for compliance or control?**
- **What must change in system design?**
- **What must change in O & M to make the accuracy sustainable?**
- **What must change in Reference Methods and stack testing procedures to support low NO_x?**
- **What must change in monitoring equipment to enable low NO_x (and NH₃) measurement?**

Systems Approaches

- **Dilution -**

- **Concentrations too low for practical accurate measurements**
- **Systems cost**
- **Doesn't eliminate NH_3 contamination**
- **Wet basis, requires water measurement (system bias)**

- **Hot/Wet**

- **Doesn't eliminate NH_3 contamination**
- **Heated analyzers - cost**
- **Wet basis, requires water measurement (system bias)**


Conventional Extractive

- ***Results show excellent accuracy***
- ***Dry basis***
 - **Same as reference method**
 - Ease of certification
 - Direct reporting
 - **No water measurement biases**
- ***Simpler system design***
- ***Lower NO_x bias further by moving NO_x Converter to sample point***
 - **Reduces bias from NO₂ loss**
 - **Makes system maintenance less critical**


Standard Test Conditions

- **NO/NO₂ :** variable 1-15 ppm
- **Ammonia :** 0-15 ppm
- **CO₂ :** 0-5% vol
- **Water :** 10% vol


Test System Diagram




Impinger Material Effects On NO₂ Absorption



NO₂ Transport Through Sample Cooler



NO₂ Loss: Impact on Certification Accuracy



Conclusions: NOx Only

- ***Down to 1ppm with up to 70% NO₂ is measurable to better than ±5%***
 - **Must use Low NOx components in system**
 - **System must be kept “Low NOx” clean**
 - **Chemi Analyzer must not have CO₂ error**
 - **High NOx exposure will bias results in a conventional system design**
- ***Stack tester***
 - **Low NOx Reference System**
 - **Low NOx measurement familiarity**


Reduce “Sensitivities”

- **NO₂ is the sensitive point**
 - Permeates Sample line
 - Soluble in water (accounts for cooler loss)
 - Chemically reactive
- **System components**
 - Clean sample line
 - Treated sampling system components (Durinert)

Eliminate NO₂ Biases: Do Conversion at the Sampling Point

- ***Eliminates NO₂ bias***
 - **High levels of NO₂ @ startup/shutdown**
 - **Loss in sample line**
 - **Loss in water removal system**
- ***Converter issues***
 - **>95% conversion efficiency @ 2 l/min**
 - **Reliable – less maintenance than sample filter**
- ***Can be adapted to NH₃ measurement***

On Stack NO_2 Conversion: Improvement in Relative Accuracy



◆ NO2 Loss With On Stack Conversion ▲ Relative Accuracy
■ Relative Accuracy ■ NO2 Absorption

Add an SCR (NH_3)

- ***NO_x Biases***

- Variable NO_2 Losses - $\text{NH}_3 + \text{NO}_2$
- Analyzer sample cell contamination
- Sample line contamination

- ***Variable NH_3 Losses – up to 100%***

- Presence of acidic gases (CO_2 , SO_2 , NO_2 ...)
- Sample line

NOx Measurement with SCR

- ***Remove NH_3 at sample point for NOx only***
 - **Minimizes system contamination**
 - **Eliminates NH_3 interference**
 - **$\text{NH}_3 + \text{O}_2 = \text{NO}$ in typical NOx converter**
 - **Even with carbon converter, NH_3 contamination is an issue**
- ***Must deal with NH_3 Scrubber issues***
 - **H_3PO_4 is most reliable system**
 - **NO_2 Loss**

Ammonia Scrubber

- ***Eliminates usual NH_3 Scrubber problems***
 - **90°C operation eliminates condensate issue**
- ***Does remove 12% of NO_2***
 - **Our data shows this is repeatable from 0.5–15 ppm NO_2**
 - **Not an issue in normal turbine operation where NO_2 is only 5-20% of NO_x (@10% NO_2 , 12% loss is only a 1.2% bias in the NO_x value)**
 - **If 12% NO_2 loss is an issue, NO_2 Selective Converter in front of scrubber eliminates problem**

On Stack Converter Performance

- ***Inconel/stainless converter***
 - **NO_2 : 97.3% @ 2 l/min**
 - **NH_3 : >90% @ 2 l/min**
 - **Synergistic NO_x/NH_3 effect**
- ***Low temperature carbon converter***
 - **NO_2 : 98% @ 2 l/min**
 - **NH_3 : <1% @ 2 l/min**

NOx Measurement Conclusion

- **Certifiable NOx measurements are possible with conventional extractive systems down to 1ppm NOx even with high NO₂ present and in the presence of low ppm NH₃**
- **Errors/Biases can be reduced by conversion of NO₂ to NO at the sampling point**
- **Ammonia can be reliably removed as an interferent when SCR's are in use**