

# **Pilot Plant Testing of Piperazine (PZ) with High T Regeneration**

Gary T. Rochelle (PI) & Eric Chen  
The University of Texas at Austin

Katherine Dombrowski (PM), URS

Andrew Sexton (TE), Trimeric

Bruce Lani, DOE PM

Objective is to demonstrate PZ with advanced regeneration at 150°C in coal-fired flue gas

PZ

- Optimize process
- Demonstrate solvent robustness


Regeneration

- Advanced flash stripper (AFS)

Aerosols

- Formation and characterization
- Control

# Phased testing at UT SRP and NCCC to optimize PZ absorption/regeneration



# Budget Period 1

\$1.65 M Federal Share

\$0.92 M Cost Share

---


\$ 2.57 M Total BP1

## Cost share by CO<sub>2</sub> Capture Pilot Plant Project (C2P3)



5m Piperazine is a Superior Solvent

# Solubility Window for 5 m & 8 m PZ



# Piperazine: Superior Energy Performance

Amine	m	$k'_{g,avg} * 1e7$	$\mu$	$\Delta C_{\mu}$	$T_{max}$
		mol/s·Pa·m <sup>2</sup>	cP	mol/kg	C
<b>PZ</b>	<b>8</b>	<b>8.5</b>	<b>11</b>	<b>0.84</b>	<b>163</b>
	<b>5</b>	<b>11.3</b>	<b>4</b>	<b>0.81</b>	<b>163</b>
AMP/PZ	4_2	8.6	5	0.90	128
MEA	7	4.3	3	0.67	121
MDEA/PZ	5_5	8.5	13	0.91	117

# Absorber Performance

40°C Intercooling

	5 m PZ	8 m PZ
<b>Lean Ldg at solid limit (mol CO<sub>2</sub>/mol alk)</b>	0.22	0.26
<b>Rich Loading (mol CO<sub>2</sub>/mol alk.)</b>	0.40	0.40
<b>L/G (mol/mol)</b>	3.03	2.55
<b>Equivalent Work (kJ/mol CO<sub>2</sub>)</b>	<b>36.0</b>	<b>36.3</b>
<b>Packing Required (m<sup>2</sup>/mol CO<sub>2</sub>)</b>	<b>126</b>	<b>298</b>



# PZ: superior solvent management

## Resistant to oxidation

- Cyclic : PZ (160C) = 1.3    MEA (120C) = 4.7 mM/hr

## Volatility just right


- At lean absorber: PZ = 8    MEA=30 ppm
- Thermal reclaiming removes nonvolatile impurities
- PZ & MEA may condense out as aerosols in absorber

## Nitrosamine manageable


- $\text{PZ} + \text{NO}_2/\text{NO}_2^- \rightarrow \text{mononitrosopiperazine (MNPZ)}$
- Decomposes at 150°C giving 1 mM MNPZ at SS

The Advanced Flash Stripper (AFS)  
minimizes Energy Use and Capital Cost.


# Irreversibility of simple stripper using 5 m PZ




# Advanced flash stripper using 5 m PZ




# Irreversibility of AFS using 5 m PZ



# Total Annualized Cost of Regeneration (Does not include absorber)



# Total Energy



AFS saves 10% over SS  
 (\$/metric ton CO<sub>2</sub> Captured, not rigorous DOE method)  
 (593 MWe Gross)

	MEA-SS	PZ-SS	PZ-AFS
Energy Derating (MW <sub>e</sub> )	145	97.5	90.1
CAPEX	22	22.1	19.4
OPEX	37	25.1	23.2
Cost of CO <sub>2</sub> Capture (excluding TS&M)	59.5 (1.00)	47.2 (0.79)	42.6 (0.72)



Amine Aerosols can be measured  
by FTIR and  
Phase Doppler Interferometer (PDI).

# Amine aerosols cause high amine emissions

## Nucleation sites in flue gas

- $\text{SO}_3/\text{H}_2\text{SO}_4$
- Submicron fly ash
- $\text{SO}_2$ /amine

## + Amine condensation


- Amine/ $\text{CO}_2$ / $\text{H}_2\text{O}$  from solvent to aerosol

## + Poor collection of small drops in water wash


---

= Unacceptable amine emissions

# Effect of H<sub>2</sub>SO<sub>4</sub> Injection FTIR Absorber out




# Effect of 25 ppm SO<sub>2</sub> on PZ Aerosol



# Phase-Doppler Interferometer (PDI)


Size & concentration: 0.5 – 10  $\mu\text{m}$  up to  $10^6$  particle/cm<sup>3</sup>

2G Bypass Extractive Sampler (tested 11/13)




# PDI at Absorber Outlet - Startup

(11/22/2013)



# Absorber Outlet – Steady-State

(LVI H<sub>2</sub>SO<sub>4</sub>: 11/22/2013)



- Use custom transmitter/receiver
  - to see down to  $0.1 \mu\text{m}$
- Use sapphire heated windows
  - to prevent liquid sheeting
- Set windows in flow body
  - To minimize wall geometry effects



# Aerosol and AFS Test Plans for SRP 2014

- Energy performance of AFS
- Energy performance of 5 m PZ vs. 8 m PZ
- Aerosol formation
  - Add  $\text{SO}_2$  and  $\text{H}_2\text{SO}_4$  to the inlet gas
  - Use 3G PDI purchased by NCCC
  - Manual and FTIR measurements of amines
  - Impingement tray at top of the absorber

# Conclusions

- 5 m PZ is a superior, demonstrated solvent.
- The advanced flash stripper provides 10% better energy performance for PZ and other solvents.
- Aerosol measurements by FTIR and PDI will quantify aerosol emissions for further control.

- **Acknowledgement:** “This material is based on work supported in part by the Department of Energy under Award Number DE-FE0005654.”
- **Disclaimer:** “This report was prepared as an account of work sponsored by an agency of the United States Government. Neither the United States Government nor any agency thereof, nor any of their employees, makes any warranty, express or implied, or assumes any legal liability or responsibility for the accuracy, completeness, or usefulness of any information, apparatus, product, or process disclosed, or represents that its use would not infringe privately owned rights. Reference herein to any specific commercial product, process, or service by trade name, trademark, manufacturer, or otherwise does not necessarily constitute or imply its endorsement, recommendation, or favoring by the United States Government or any agency thereof. The views and opinions of authors expressed herein do not necessarily state or reflect those of the United States Government or any agency thereof.”



[www.GHGT.info](http://www.GHGT.info)

# GHGT-12

October 5 - 9, 2014 | AUSTIN, TX - USA