

# Hybrid Encapsulated Ionic Liquids for Post-Combustion Carbon Dioxide (CO<sub>2</sub>) Capture

Federal Award No. DE-FE0026465 - David Lang

Joan F. Brennecke

Thomas F. Degnan, Jr.

Mark J. McCready

Mark A. Stadtherr

Dept. of Chemical and Biomolecular Engineering

University of Notre Dame

Notre Dame, IN 46556 USA

August 10, 2016

Project Initiation: 10/1/15



Partner: Joshua K. Stolaroff  
Lawrence Livermore National Laboratory




# Ionic Liquids


- Pure salts that are liquid around ambient temperature
  - Not simple salts like alkali salts
- Many favorable properties
  - **Nonvolatile**
  - Anhydrous
  - High thermal stability
  - Huge chemical diversity



Examples of cations



Examples of anions




# Ionic Liquids for CO<sub>2</sub> Capture – Previous Work

- Equimolar capacity – 1 mol CO<sub>2</sub>/mol IL

# AHA – aprotic heterocyclic anions


- Retain amine in ring structure
- Further reduce free hydrogens to reduce hydrogen bonding



# Ionic Liquids for CO<sub>2</sub> Capture – Previous Work

- Equimolar capacity – 1 mol CO<sub>2</sub>/mol IL
- No viscosity increase upon reaction with CO<sub>2</sub>



# Eliminate Viscosity Increase by Using AHA – aprotic heterocyclic anions



# Ionic Liquids for CO<sub>2</sub> Capture – Previous Work

- Equimolar capacity – 1 mol CO<sub>2</sub>/mol IL
- No viscosity increase upon reaction with CO<sub>2</sub>
- Tunable enthalpy of reaction


# Tuning Reaction Enthalpy of AHA ILs



- ◆ [Inda]
- [Bnlm]
- ▲ [6-BrBnlm]
- × [2-SCH<sub>3</sub>Bnlm]
- × [2-CNPyr]<sup>a</sup>
- [3-CF<sub>3</sub>Pyr]<sup>a</sup>
- + [3-CH<sub>3</sub>-5-CF<sub>3</sub>Pyr]
- [3-Triaz]
- [4-Triaz]

$\Delta H_{\text{rxn}}$  (kJ/mol)

- 54
- 52
- 48
- 41
- 45
- 44
- 41
- 37
- 42



Seo et al., JPC B, 2014, 118, 5740




# Ionic Liquids for CO<sub>2</sub> Capture – Previous Work

- Equimolar capacity – 1 mol CO<sub>2</sub>/mol IL
- No viscosity increase upon reaction with CO<sub>2</sub>
- Tunable enthalpy of reaction
- Phase change ionic liquids

# CO<sub>2</sub> Capture with Phase Change Material

Absorbent goes from solid to liquid when reacts with CO<sub>2</sub>, absorbing heat



Absorbent goes from liquid to solid when releases CO<sub>2</sub>, releasing heat

'Melting' of absorbent reduces cooling duty



Heat duty in stripper reduced by the heat of fusion of the phase change material

# CO<sub>2</sub> Capture with Phase Change Material

## Absorber



Remove  
50 kJ/mol





Add  
20 kJ/mol

$Q_{net} = \text{Remove } 30 \text{ kJ/mol}$

## Regenerator



Add  
50 kJ/mol




Remove  
20 kJ/mol

$Q_{net} = \text{Add } 30 \text{ kJ/mol}$

# Phase Change Ionic Material


70 °C




Pure material;  $T_m=166$  °C; no  $\text{CO}_2$



60 mbar  $\text{CO}_2$





100 mbar  $\text{CO}_2$





150 mbar  $\text{CO}_2$

# Challenge: High Viscosity/Poor Mass Transfer



# Microencapsulation

- Idea: improve mass transfer by increasing mass transfer AREA
- Successfully demonstrated by LLNL for other CO<sub>2</sub> sorbents



- Multiple solvents, shell materials, and sizes produced

# Selection of ILs and PCILs


- Evaluated 9 IL and 10 PCIL candidates
- Criteria
  - Melting point
  - Thermal stability
  - Enthalpy of reaction with CO<sub>2</sub> between -45 and -60 kJ/mol
  - Viscosity
  - $T_m^{\text{complex}} < T_m^{\text{pure}}$  for PCIL
- ILs: NDIL0230 and NDIL0336
- PCILs: NDIL0309 and NDIL0335

# Bulk IL Recyclability Testing


- Leading IL candidate – PCIL0230
- Room temperature in volumetric apparatus
- Exposed to CO<sub>2</sub> at 1 bar; determine equilibrium uptake
- Heat at 60 °C and vacuum (~5 torr) for 5 hours to desorb
- Reabsorb at RT and 1 bar CO<sub>2</sub>
- Repeat



# IL Recyclability Testing




# Identification of IL and PCIL-compatible shell material and/or curing process



Scheme 1: Formulation of thio-lene shell material

Two new shell materials were created for CO<sub>2</sub> capture solvents



Scheme 1: Formulation of SiTRIS shell material




# Identification of IL and PCIL-compatible shell material and/or curing process



Systematic core-shell screening identified promising pairs

Good properties for encapsulation	Marginal properties for encapsulation	Not compatible
-----------------------------------	---------------------------------------	----------------

	NDIL0274	NDIL0252	NDIL0231	NDIL0231 1:1 wt. water	NDIL0230	NDIL0230 1:1 wt. water	NDIL0309 (solid powder)	NDIL0309 w/ 1:1 wt. water
<i>Semi-cosil</i>				✗		✗		
<i>Thiol-ene</i>				✗				✓
<i>SiTRIS (80:20)</i>				✓		✓ (w/ 1:3)		





✗ encapsulation attempted and failed  
✓ encapsulation succeeded

# Encapsulated IL Production

NDIL0231-SiTRIS microcapsules washed and dried at 60 °C x 6 hours:




Washed with DI water repeatedly and then dried on mesh holder




Encapsulating neat ILs remains challenging. Current strategy: dilute ILs in water and dry them after production

Great core-shell integrity and uniformity

# Fast CO<sub>2</sub> Uptake by Encapsulated ILs




# Fast CO<sub>2</sub> Uptake by Encapsulated ILs



# Encapsulate IL Maintains Capacity

Solubility of CO<sub>2</sub> in NDIL0230 in SiTRIS at 22°C



# Summary

- Successful synthesis, purification and testing of ILs and PCILs
- Successful encapsulation of ILs and PCILs
- Demonstration of fast CO<sub>2</sub> uptake by encapsulated IL
- Encapsulated IL maintains capacity
- Future work
  - Further shell material improvements
  - Dealing with water and impurities
  - Demonstration in laboratory scale unit



# Reprotonation Equilibrium and Kinetics

Desired



Not Desired



Not Desired

