

*the Energy to Lead*

# Energy Efficient GO-PEEK Hybrid Membrane Process for Post-combustion CO<sub>2</sub> Capture

DOE Contract No. DE-FE0026383

---

Shiguang Li

*Gas Technology Institute (GTI)*

Miao Yu

*University of South Carolina (USC), and Rensselaer Polytechnic Institute (RPI)*

Yong Ding

*Air Liquide Advanced Separations (ALaS)*




CO<sub>2</sub> Capture Technology Project Review Meeting

August 13 - 17, 2018, Pittsburgh, PA




# Introduction to GTI

- Research organization, providing energy and environmental solutions to the government and industry since 1941
- Facilities: 18 acre campus near Chicago








**OFFICE**  
**SUBSIDIARY**



# GO-PEEK project overview

- **Performance period**: Oct. 1, 2015 – Sep. 30, 2019
- **Funding**: \$1,999,995 from DOE; \$500,000 cost share
- **Objectives**: Develop a hybrid membrane process combining a graphene oxide (GO) gas separation membrane unit and a PEEK hollow fiber membrane contactor (HFMC) unit to capture  $\geq 90\%$  of the  $\text{CO}_2$  from flue gases with 95%  $\text{CO}_2$  purity at a cost of electricity 30% less than the baseline  $\text{CO}_2$  capture approach

<b><u>Team:</u></b>	<b>Member</b>	<b>Roles</b>
		<ul style="list-style-type: none"> <li>• Project management and planning</li> <li>• Quality control and <math>\text{CO}_2</math> capture performance tests</li> </ul>
	 	<ul style="list-style-type: none"> <li>• GO membrane development</li> </ul>
	 <b>ALaS</b>	<ul style="list-style-type: none"> <li>• PEEK membrane development</li> </ul>
	 <b>TRIMERIC CORPORATION</b>	<ul style="list-style-type: none"> <li>■ High-level technical &amp; economic feasibility study</li> </ul>

GO = graphene oxide; PEEK = polyether ether ketone; HFMC = hollow fiber membrane contactor

# GO membrane technology based on our work published in *Science* and *Nature Communications*



Ultrathin, Molecular-Sieving Graphene Oxide Membranes for Selective Hydrogen Separation

Hang Li *et al.*

*Science* **342**, 95 (2013);

DOI: 10.1126/science.1236686





ARTICLE


DOI: [10.1038/s41467-017-02318-1](https://doi.org/10.1038/s41467-017-02318-1)

OPEN

Ultrathin graphene oxide-based hollow fiber membranes with brush-like CO<sub>2</sub>-philic agent for highly efficient CO<sub>2</sub> capture

Fanglei Zhou<sup>1</sup>, Huynh Ngoc Tien<sup>2</sup>, Weiwei L. Xu<sup>2</sup>, Jung-Tsai Chen<sup>2</sup>, Qiuli Liu<sup>2</sup>, Ethan Hicks <sup>2</sup>, Mahdi Fathizadeh <sup>2</sup>, Shiguang Li<sup>3</sup> & Miao Yu<sup>1</sup>

# Singular PEEK HFMC technology currently at pilot scale development stage (DE-FE0012829)



Membrane contactor: high surface area device that facilitates mass transfer



Commercial-sized (8-inch-diameter) modules with intrinsic  $CO_2$  permeance of ~2,000 GPU used in pilot scale testing




NCCC PSTU system (0.5 MW<sub>e</sub>)


GTI HFMC system (0.5 MW<sub>e</sub>)

Plant constructed and installed at NCCC

Achieved steady state performance during 224-h continuous testing with a single 8-inch-diameter module at NCCC with actual flue gas




# Process description





- GO-PEEK uses a conventional gas separation membrane unit to capture bulk of the CO<sub>2</sub> from coal-fired flue gas followed by a PEEK HFMC unit to further capture CO<sub>2</sub> to achieve DOE's technical target
- Takes advantages of the “Pros” of two processes while overcoming their “Cons”, offering opportunity to explore further reductions in CO<sub>2</sub> capture cost

# GO-PEEK technical goals




# Progress on PEEK Membranes






# Under the current program, we have been developing PEEK fibers with intrinsic CO<sub>2</sub> permeance of 3,000 GPU




1 GPU = 3.348 x 10<sup>-10</sup> mol/m<sup>2</sup>/s/Pa

# 3<sup>rd</sup> Gen fibers developed; 2-inch-diameter module using the fibers showed CO<sub>2</sub> permeance >3,000 GPU




# PEEK membrane module effective in capturing CO<sub>2</sub> from low CO<sub>2</sub>-concentration feeds in membrane contactor



Goal of mass transfer coefficient > 3 (sec)<sup>-1</sup> achieved



# Progress on GO Membranes



**GO**: single-atomic layered, oxidized graphene



# Procedure developed for coating GO membrane on the inside surface of the hollow fiber (HF) support

PES  
fiber



Uncoated  
fiber  
surface

Coated  
fiber  
surface




Coated  
fiber cross  
section

PES = polyethersulfone


# Challenge: initial GO membrane performance needed significant improvement

- Initial GO membrane performance under simulated flue gas condition (humidified 15%/85% CO<sub>2</sub>/N<sub>2</sub> mixture):
  - CO<sub>2</sub> permeance: 100 GPU; selectivity: 49




# Approaches to improve CO<sub>2</sub> permeance

- Create more structural defects on GO flake by HNO<sub>3</sub> etching




- Reduce GO flake lateral size by ultra-sonication

**W/O ultra-sonication**




**W/ ultra-sonication**




# Approach to improve CO<sub>2</sub>/N<sub>2</sub> selectivity: fill the space between GO layers with CO<sub>2</sub>-philic agent

- CO<sub>2</sub>-philic agent enables facilitated transport mechanism to separate CO<sub>2</sub> from N<sub>2</sub>



CO<sub>2</sub>-philic agent example: piperazine (PZ)




- XPS and FTIR analysis confirmed the crosslinking of PZ with GO sheets




# Cross-sectional SEM of the PZ filled GO membrane

---





# GO-PZ membrane separation performance

Feed: 15% CO<sub>2</sub>/85%N<sub>2</sub> with saturated water vapor  
Permeate: with sweep gas




# Facilitated transport mechanism

- $\text{CO}_2$ :  $2\text{CO}_2 + 2\text{RR}'\text{NH} + \text{H}_2\text{O} \rightleftharpoons \text{RR}'\text{NCOOH} + \text{RR}'\text{NH}_2^+ + \text{HCO}_3^-$



- $\text{N}_2$  has no enhancements and moves only by diffusion


# 50-h testing showed variation of performance: humidity may be controlled to achieve the best performance



**Membrane stable during 50-h testing**

EDA = Ethylenediamine; PZ = Piperazine





# GO-based membranes showed good stability in the presence of flue gas contaminants



- GO-PZ and GO-EDA membranes also stable in the presence of flue gas contaminants

# In addition to sweep gas mode, we also tested GO-based membranes with permeate side under vacuum

Feed mixture: 15%CO<sub>2</sub>/85%N<sub>2</sub> saturated with H<sub>2</sub>O vapor; temperature: 75 °C



PEI = Polyethylenimine


# >1,000 GPU CO<sub>2</sub> permeance achieved in vacuum mode with improved membrane and optimized humidity

---

Membrane	Improved GO-PZ membrane
Temperature	75 °C
Humidity	85%
Feed gas	15% CO <sub>2</sub> /85% N <sub>2</sub>
<b>CO<sub>2</sub> permeance, GPU</b>	<b>1080 ± 55</b>
<b>CO<sub>2</sub>/N<sub>2</sub> selectivity</b>	<b>650 ± 31</b>

# Future work overview/roadmap

## ■ In this project



## ■ After this project

- Bench-scale development for GO-based membranes (DE-FE0031598)



# Summary

---

- We are developing a transformational hybrid process for CO<sub>2</sub> capture combining a conventional gas membrane unit and a HFMC unit
- **The 3<sup>rd</sup> Generation PEEK fiber** developed to date
  - Fibers with intrinsic CO<sub>2</sub> permeance >3,000 GPU at 25°C demonstrated in 2-inch-diameter modules
  - A 2-inch-diameter module containing 3<sup>rd</sup> generation fibers effective in capturing CO<sub>2</sub> from low CO<sub>2</sub>-concentration feeds with aMDEA solvent
- **GO-based membrane** developed to date
  - CO<sub>2</sub> permeance > 1,000 GPU and  $\alpha_{\text{CO}_2/\text{N}_2} > 600$  achieved both in sweep gas and vacuum permeation modes using simulated coal flue gas
  - Good stability in the presence of flue gas contaminants
- Future work will focus on integrated GO-PEEK process testing and TEA

# Acknowledgements

---

- Financial and technical support



DE-FE0026383

- DOE NETL Steven Mascaro. José Figueroa and Lynn Brickett
- Dr. Yu Group
  - Fanglei Zhou
  - Hongchao Mao
  - Huynh Ngoc Tien
  - Jarvis Chen
  - Mahdi Fathizadeh

# Disclaimer

---

This presentation was prepared by Gas Technology Institute (GTI) as an account of work sponsored by an agency of the United States Government. Neither GTI, the United States Government nor any agency thereof, nor any of their employees, makes any warranty, express or implied, or assumes any legal liability or responsibility for the accuracy, completeness, or usefulness of any information, apparatus, product, or process disclosed, or represents that its use would not infringe privately owned rights. Reference herein to any specific commercial product, process, or service by trade name, trademark, manufacturer, or otherwise does not necessarily constitute or imply its endorsement, recommendation, or favoring by the United States Government or any agency thereof. The views and opinions of authors herein do not necessarily state or reflect those of the United States Government or any agency thereof.