



Energy Efficient GO-PEEK Hybrid Membrane Process for Post-combustion CO₂ Capture

DOE Contract No. DE-FE0026383

Shiguang Li, Naomi Klinghoffer, Travis Pyrzynski, Howard Meyer

Gas Technology Institute (GTI)

Miao Yu, Fanglei Zhou, Huynh Ngoc Tien, Jarvis Chen

University of South Carolina (USC)

Yong Ding

Air Liquide Advanced Separations (ALaS)

BP1 Review Meeting (NETL-Pittsburgh)

March 22, 2017





Project at a glance

- **Status:** Currently in BP1 (October 1, 2015 – March 31, 2017) with a budget of \$814,748 from DOE (\$255,624 cost share)
- **Accomplishments:**
 - Graphene oxide (GO) membranes developed: CO₂ permeance > 1,000 GPU, $\alpha_{\text{CO}_2/\text{N}_2} > 600$ for simulated flue gas at 80°C
 - The 3rd generation polyether ether ketone (PEEK) fibers developed: intrinsic CO₂ permeance > 3,000 GPU at 22-60°C
- **Schedule and budget:** All BP1 Milestones and Success Criteria met
 - Ahead of schedule (under budget) to complete BP1 work
 - **Overall, we are ready for BP2 starting April 1, 2017**
- **Issue(s):**
 - PEEK: no major issues identified
 - GO: stability needs to be improved through optimization of membrane preparation and operation conditions (major scope of the BP2)


Project overview

- **Performance period**: Oct. 1, 2015 – Sep. 30, 2018
- **Funding**: \$1,999,995 from DOE; \$500,000 cost share
- **Objectives**: Develop a hybrid membrane process combining a graphene oxide (GO) gas separation membrane configuration unit and a PEEK hollow fiber membrane contactor (HFMC) unit to capture $\geq 90\%$ of the CO_2 from flue gases with 95% CO_2 purity at a cost of electricity 30% less than the baseline CO_2 capture approach

- **Team:**

Member	Roles
	<ul style="list-style-type: none"> • Project management and planning • Quality control and CO_2 capture performance tests
	<ul style="list-style-type: none"> • GO membrane development
 ALaS	<ul style="list-style-type: none"> • PEEK membrane development
 TRIMERIC CORPORATION	<ul style="list-style-type: none"> ■ High-level technical & economic feasibility study

Process description



CO₂/SO₂ selectivity through GO membrane will be tested in the current program:

- Case 1:** SO₂ permeates through the membrane, a caustic scrubber is needed before the GO membrane
- Case 2:** SO₂ stays in the retentate, scrubber not needed; HFMC can handle 150 ppmv SO₂ (DE-FE-0004787)

GO membrane technology based on our pioneering work published in *Science* (2013, 342 (6154) 95)




Ultrathin, Molecular-Sieving Graphene Oxide Membranes for Selective Hydrogen Separation

Hang Li *et al.*

Science **342**, 95 (2013);

DOI: 10.1126/science.1236686




■ Contribution of the paper:

- Structural defects on GO flakes can be controlled as transport pathway for selective gas separations


Single-layered GO flake
prepared as thin as 1 nm

GO-PEEK technical goals




Technical challenges of applying GO-PEEK process to existing coal-fired plants

- **GO membrane performance** — Needs significant improvement







- **Durability** — Long-term stability of both GO and PEEK membranes
- **Scale-up and cost reduction** — Both membranes in hollow fiber format

Progress on GO Membranes



GO: single-atomic layered, oxidized graphene

Large quantity of GO prepared, characterizations confirmed morphology, composition and structure






- Typical membrane preparation: 50 mL dispersion with 0.5 mg GO is needed

- Confirmation: power prepared is single layered GO with various functional groups

Before you make/improve a membrane, you have to know:


What is the separation mechanism?



- The smaller molecule CO_2 diffuses faster than the larger molecule N_2 which also favors the separation of CO_2 over N_2

- Preferential adsorption of CO_2 over N_2 would favor separating CO_2 over N_2


CO₂/N₂/H₂O transport mechanism through layered GO membrane: solution diffusion




Approach 1 for improvement of membrane performance: reducing GO flake lateral size by ultra-sonication

GO type	Description
I IA	Original GO prepared by modified Hummers method <i>GO-COOH (GO functionalized with COOH group)</i>
II	GO with enlarged structural defects etched by HNO_3 oxidation
III	GO with reduced lateral size by ultra-sonication
IIIA	<i>Prepared by 1 h ultra-sonication</i>
IIIB	<i>Prepared by 2 h ultra-sonication</i>
IIIC	<i>Prepared by 3 h ultra-sonication</i>
IIID	<i>Prepared by 4 h ultra-sonication</i>
IIIE	<i>Prepared by 5 h ultra-sonication</i>
IIIF	<i>Prepared by 6 h ultra-sonication</i>



W/O ultra-sonication



W/ ultra-sonication




Dynamic light scattering showed sonication effectively reduces GO size




GO after 1-h sonication had a dual size distribution with two peaks centered at 200 and 5,000 nm. After 3-h sonication, the large-size GO disappeared and the GO particle sizes were smaller than approximately 150 nm. Further sonication led to a slight decrease in GO particle size.

AFM images (Type I, Type IIIA and Type IIIE) confirmed the reduced GO size


The scale bar is 1 μm



GO-Type I



GO-Type IIIA



GO-Type IIIE


Approach 2: PES support pre-washing to remove agents (mainly glycols) and thus reduce resistance from substrate

Permeance for the PES substrate


Support	Permeance* (GPU)	
	N ₂	CO ₂
Untreated support	480	530
Pretreated support	3,400	3,400

*Feed condition: 15% CO₂/85%N₂ with saturated water vapor at 24 °C; ΔP across the membrane was 1 to 5 psi.

Field emission scanning electron microscope images showed support pores became larger after washing




Support before washing



Support after washing



Procedure developed for coating GO-based membrane on hollow fiber (HF) support



Coating procedure:


1. Valves A and B are open, GO dispersion flows continuously in hollow fiber
2. Vacuum filtration is conducted for a controlled time; and
3. Valves A and B are closed; coated fiber stays under vacuum for a controlled time

GO-based membranes as thin as 9 nm




GO-based membranes sealed in a mini-module for gas permeation testing

Permeation testing unit




GO-based membranes for CO₂/N₂ mixture separation under wet condition


Feed: 15% CO₂/85%N₂ with saturated water vapor
Permeate: with sweep gas



Progression of GO membrane development




Comparison to other CO₂/N₂ separation membranes



1. Ho, et al., 2015 NETL CO₂ Capture Technology Meeting, June 23-26, 2015, Pittsburgh.
2. Merkel, et al., Ibid.
3. Venna, Ibid.
4. Bhandari, 2014 NETL CO₂ Capture Technology Meeting, July 29-August 1, 2014, Pittsburgh.

Robeson, J. Membrane Sci. **2008**, Vol. 320, p390
Note: Polymer data points (red): 100 nm membrane thickness assumed

Preliminary stability testing indicated operation condition needs to be optimized during BP2



Area	CO ₂ /N ₂ Selectivity	RH (feed)
I	>400	100
II	<200	100
III	<20	0
IV	>400	100
V	Stop	Stop



Area II: water condensation in membrane due to a low temperature of sweep helium

Scaleup consideration




This scale of module to be used in large bench scale and to be tested at NCCC

Progress on PEEK Membranes




Under the current program, we are developing PEEK fibers with intrinsic CO₂ permeance of 3,000 GPU




1 GPU = 1 x 10⁻⁶ cm³ (STP)/cm² • s • cmHg

Air Liquide's micro module lab testing



Air Liquide's lab testing system



Eight types of fibers were investigated

Sample No.	Fiber OD (Micron)	Fiber ID (Micron)	CO ₂ permeance* (GPU)
78-33-3A	582	350	2,300
78-33-3B	582	350	2,500
78-118-3A	569	358	2,300
78-118-3B	569	358	2,800
78-117-5A	569	353	3,400
78-117-5B	569	353	3,400
78-117-5C	569	353	3,700
78-117-5D	569	353	3,800


Temperature: 25°C, feed pressure: ~ 5 psig

2-inch module 2PG809 containing 78-117-5A fibers (CO₂ permeance of 3,400 GPU)

Single gas permeances for CO₂ at 25°C


Feed pressure (psig)	Retentate side pressure (psig)	Permeate side pressure (psig)	Intrinsic CO ₂ permeance (GPU)
12	11.4	0.43	2,750
15	14.3	0.65	2,750

Another 2-inch module 2PG818 containing 78-117-5C fibers (CO₂ permeance of 3,700 GPU)




Intrinsic CO₂ permeance as high as 3,000-3,300 GPU at 25°C, meeting our goal of 3,000 GPU


Intrinsic CO₂ permeance stable



CO₂ flux in contactor vs. intrinsic CO₂ permeance



PEEK membrane module effective in capturing CO₂ from low CO₂-concentration feeds in membrane contactor



BP1 success criteria met

- 1) GO membranes exhibit CO_2/N_2 selectivity ≥ 55 and CO_2 permeance $\geq 1,000$ GPU; and
- 2) PEEK hollow fiber membrane intrinsic CO_2 permeance of 3,000 GPU achieved.

BP1 all milestones met

Milestone	Milestone Title/Description	Planned Completion Date	Actual Completion Date
1.1	Updated Project Management Plan	11/30/15	11/25/15
1.2	Kickoff Meeting	12/31/15	12/07/15
2.1	GO membranes with thickness <50 nm successfully prepared on porous hollow fiber supports	02/28/16	02/20/16
4.1	Achieve membrane intrinsic CO ₂ permeances of 3,000 GPU for PEEK hollow fiber modules	08/31/16	10/24/16
5.1	GO membranes with thickness <25 nm successfully prepared on porous hollow fiber supports	12/31/16	12/03/16
5.2	GO membranes exhibit CO ₂ /N ₂ selectivity ≥55 and CO ₂ permeance ≥1,000 GPU	03/30/17	12/03/16

Summary for BP1 study

- We are developing a novel CO₂ capture process combining a conventional gas membrane unit and a HFMC unit
- **GO membrane** developed to date
 - CO₂ permeance > 1,000 GPU and $\alpha_{\text{CO}_2/\text{N}_2} > 600$ obtained at 80°C for a humidified CO₂/N₂ mixture
 - Superior performance to GO-based membranes reported in the literature
- **The 3rd Generation PEEK fiber** developed to date
 - Fibers with intrinsic CO₂ permeance >3,000 GPU at 25°C
 - 78-117-5A fiber down selected for BP2 study
 - Membrane module effective in capturing CO₂ from low CO₂-concentration feeds with aMDEA solvent
- Ahead of schedule (under budget) to complete BP1 work
 - All milestone and success criteria met
 - **Ready for BP2 starting April 1, 2017**

BP2 overview/roadmap

GO Membrane Development

Task 6.0 (**USC**) – Further GO optimization

Task 7.0 (**GTI**) – Performance stability testing of GO membranes using simulated flue gases

Task 9.1 (**USC**) – GO membrane support for integrated testing

Integrated GO-PEEK Hybrid System

Task 8.0 (**GTI**) – Modification of an existing HFMC apparatus to GO-PEEK system

Task 10.0 (**GTI**) – CO₂ capture testing using integrated GO-PEEK hybrid system

Task 11.0 (**Trimeric**) – High-level techno-economic feasibility study

PEEK Membrane Development

Task 9.2 (**ALaS**) – PEEK membrane support for integrated testing

Requesting...

- Continuation of BP2
- BP2 budget of \$1,185,247
 - GTI's team to provide \$244,376 cost share

After the current project, steps can be taken to further reduce capture cost

- Increase CO₂ permeance for GO membrane
- Improve manufacture process to lower membrane costs
- Use advanced solvents instead of aMDEA
- Use novel process for solvent regeneration
 - e.g. gas pressurized stripping reported by Carbon Capture Scientific¹
 - e.g. advanced flash regeneration by UT²

1: Scott Chen et al., Ibid

2. Gary Rochelle, 2016 NETL CO2 Capture Technology Meeting, August 8-12, 2016, Pittsburgh.

Acknowledgements

- Financial support



- DOE NETL José Figueroa