

Polyphosphazene Based Membranes for Gas Separation

Dr. Hunaid Nulwala
Liquid Ion Solutions LLC
Pittsburgh, PA




Membrane/Solvent Integrated Process




Membrane Needs

- Commercial membrane materials
 - Selectivity ≈ 40
 - Permeability ≈ 200
- Less conventional membrane needed to make substantial improvements
 - Supported liquids
 - Mixed matrix membranes
- Mixed matrix membranes
 - Better particles (Zeolites, MOFs)
 - Improved polymers
 - Controlled interaction of polymer with particles

The Trouble with Mixed Matrix Membranes





**“True” MMM
Transport**





**Particle
Bypass**

Insight





Interface

If you can't beat 'em, join 'em!



- Makes use of envelopment effects which have plagued mixed matrix membranes
- Diffusion phenomena determined by interactions with the particle and polymer surface
- Possibility of using simple nanoparticle fillers
- Advanced polymers allow an excellent starting point



Plan of Attack for Mixed Matrix Membranes




5-10 nm

- Use simple nanoparticle fillers
- Surface modify the particles to tune optimal interactions with CO_2 and the polymer
- Employ an advanced polymer with good compatibility and CO_2 transport properties
- Create a membrane in which diffusion phenomena are determined by interactions with the particle and polymer surface

Polymer of Choice





Polymer Screening



Membrane Fabrication

Challenges

- Not a film former
- Sticky
- Does not have required mechanical properties




10-12 microns

HV	Mag	WD	Spot	Sig	HFW
0.0 kV	500x	9.6 mm	5.0	BSE	0.60 mm


300.0µm

Gas Testing Systems and Performance Testing





- Mixed Gas Selectivities
- Testing in Presence of Moisture
- Testing in Presence of Contaminants

Polymer Membrane Results






Surface Functionalized Nanoparticles



Interfacial Enveloped Composite Membranes


- Multiple glass transition temperature
- Multiple regions



← 40% nano particles
← 10% nano particles

Membrane performance



	Selectivity	Permeability (Barrer)
MEEP	62	250
MEEP-IPN	42	500
MEEP-IPN 10%	41	659
MEEP-IPN 40%	44	1609



Response	Percentage
Yes, the current system is the best way to run the country	85%
No, the current system is not the best way to run the country	15%



Cusp of a Major Breakthrough



Acknowledgement

Liquid Ion Solutions, Carbon Capture Scientific and Penn State University gratefully acknowledge the support of the United States Department of Energy's National Energy Technology Laboratory under agreement DE-FE0026464, which is responsible for funding the work presented.

- Dr. Scott Chen
- Dr. Zijiang Pan
- Dr. Zhiwei Li

- Prof. Harry Allcock
- Dr. Zhongjing Li

- Dr. David Luebke
- Brian Radka

Permeability Vs. Permeance

