

Overview of Fiber Optic Sensing for Energy Applications

Anbo Wang


Center for Photonics Technology

Virginia Polytechnic Institute and State University

Blacksburg, VA 24061-0111

Tel: (540)231-4363 E-mail: awang@vt.edu

Principle of an optical fiber




When θ is greater than $\theta_c = \sin^{-1}(n_2/n_1)$, the light can be guided.

Why fiber sensors attractive?

- High temperature capability
- Chemically inert
- Remote operation
- Immunity to electromagnetic interference
- Non-electrically conducting
- Sensor multiplexing/distributed measurement

Overview of CPT Sensor Research



▲ *Fabrication and instrumentation*

PHOTONIC SENSORS

Applications ▼

Gasifier
Temperature
Monitoring



Sapphire fiber temperature sensor testing in TECO coal gasifier

Oil Downhole
Measurement



Pressure and temperature sensors tested in Chevron oil well

Partial Discharge
Detection



Acoustic sensors (70-250kHz) tested in Northfleet 400kV transformer




Dynamic Engine
Pressure
Monitoring



Pressure sensors tested on Virginia Tech Engine



Intrinsic Fabry-Perot Sensors



$$\Delta\varphi = \frac{2nL}{\lambda} \cdot 2\pi + \varphi_o$$

λ is the light wavelength in vacuum and φ_o is a constant.



$$\Delta\varphi = \frac{2nL}{\lambda} \cdot 2\pi + \varphi_o + \Delta\varphi(L, n, \lambda)$$

“Decoding the spectra of low-finesse extrinsic optical fiber Fabry-Perot interferometers,” *Opt. Express*, 24, 23727-42 (2011).

“Toward eliminating signal demodulation jumps in optical fiber intrinsic Fabry-Perot interferometric sensors,” *J. Lightwave Tech.* 29 (13), 1913-9(2011)

“Phase Term in the Spectrogram of SMS-IFPI Fiber Sensor and Its Influence on White-Light Interferometry Based Sensor Signal Demodulation,” *Appl. Opt.*, 49, 4836 (2010).

Porous Clad Optical Fiber for High Temperature Fast Gas Sensing



Transmission Spectrum

Single-Crystal Sapphire Fiber Sensors

Silica Fiber Limitations






- 1) Thermal diffusion of germanium dopant
- 2) Glass creep under stress at elevated temperatures
- 3) Max temperature is usually between 800 and 900C.

For higher temperatures, different fibers are needed.



Sapphire Properties

- 1) High melting point (2045C)
- 2) Excellent optical transparency from near UV to several microns
- 3) Commercial availability




Sapphire Fiber Temperature Sensor









IFPI Sensor Test on NETL Engine Rig






Field Test at Tampa Electric Corporation



Example Sensors



Wavelength-Scanning TDM



Important Feature: Use weak IDENTICAL FBGs.

Acknowledgement

Thanks go to CPT faculty, staff and graduate students who were involved in the presented research.

We are also grateful to DOE NETL for their support to the presented research.