SOFC Development at GE Global Research


Kristen Brosnan GE Global Research Niskayuna, NY


14th Annual SECA Workshop Pittsburgh, PA July 23-24, 2013





Low-cost manufacturing





Advantages
Larger area / Scalable
Simplified Sealing
Low Capex / Modular
Lean Manufacturing


Thermal Spray



Leverage GE thermal spray expertise




Metal supported cell



Advantages:

Integrated anode seal
Electrolyte in compression
Improved anode electrical
contact

Increased active area Lower anode polarization Allows redesign of structures



Challenges:

Dense / hermetic electrolyte
Porous metal substrate degradation



Thermal spray manufacturing challenges



Electrolyte functions:

- 1) Transport O²⁻ ions
- 2) Separate air/fuel

Thin & dense (on porous substrate)

Crack-free / hermetic strength, residual stress

Edge sealing
Mechanical design
Thermal management







electrolyte

anode

fuel

air

support

air









interconnect



Mechanical Properties of Thermal Sprayed Coatings








Elastic Modulus and failure stresses from 4-point bend testing

Characterization of residual/thermal stresses in coatings




Sample dimensions for XRD measurements at Argonne national lab's APS facility

Residual stresses compound stresses during operation Must quantify residual stresses & thermal dependence



XRD stress analysis - YSZ




In-plane compressive strain observed



Electrolyte stress state remains favorable

Effect of Anode Reduction


Pre-reduction, 575°C



Curvature measurements are made to feed into FE model to estimate stress states

Post-reduction, 575°C


Anode ~35 MPa tension YSZ ~18 MPa compression



As anticipated, anode reduction imparts compressive stress state to electrolyte



2" cell (25 cm²) test Set-Up




25 cm² test vehicle representative of stackable architecture



Repeatability

- Manufacturing and performance database allows tracking of variables for improved understanding of process-properties relationships
- Quickly screen >250 process variables/conditions




- Destructive GR&R performed using 2 typical sample types
- < 30% GR&R on testing stations
- 50 mohm-cm² resolution

25 cm² testing enables confidence in experimental design results



Performance




Process shift & control increases performance


Capability to directly measure impacts of processing variables



Performance








 YSZ conductivity in agreement with literature values

YSZ thickness dominant ASR contributor




25 cm² Degradation



Thermal spray manufactured SOFC demonstrate stable operation




Fuel Utilization on 25 cm²



Able to achieve high single-pass fuel utilization on non-optimized flow field



Manufacturing Scale-up



Successful manufacturing scale-up: 25 cm² to 400 cm²



Summary

- Evolved thermo-mechanical FE models to support development and scale-up
- Developed database and 25cm² gauge to accelerate development
- Developed thermal spray conditions and suitable substrate to enable high fuel utilization
- Demonstrated thermal spray manufactured cell performance stability
- Scaled thermal spray manufacturing from 2.85 cm² to 25 cm² to 100 cm² to 400 cm²



Acknowledgements

- Joe Stoffa, Heather Quedenfeld and Shailesh Vora of DOE/NETL
- GE SOFC Team

 Funding provided by the US Department of Energy through cooperative agreement DE-NT0004109.

This material is based upon work supported by the Department of Energy under Award Number DE-NT0004109. However, any opinions, findings, conclusions, or recommendations expressed herein are those of the authors and do not necessarily reflect the views of the DOE.



