

Hybrid Encapsulated Ionic Liquids for Post-Combustion Carbon Dioxide (CO₂) Capture

Federal Award No. DE-FE0026465 - David Lang

Mark J. McCreedy

Thomas F. Degnan, Jr.

Dept. of Chemical and Biomolecular Engineering

University of Notre Dame

Notre Dame, IN 46556 USA

Joan F. Brennecke

Mark A. Stadtherr

McKetta Department of Chemical Engineering

University of Texas

Austin, TX 78712 USA

August 14, 2018


Project Initiation: 10/1/15

Partner: Joshua K. Stolaroff

Lawrence Livermore National Laboratory



Conceptual Process Overview




- Effectiveness of a full scale CO₂ separation/ purification from flue gas process will have the challenges:
 - Overall flow of the absorbing material
 - Need a “high capacity” absorbent,
 - ideally: good ratio: mass of CO₂/mass of absorbent
 - Energy/heat required to reverse reaction and release the CO₂
 - Higher reaction enthalpy → higher capacity... but more energy to reverse
 - Adiabatic heat rise in absorber
 - More “energetic” the absorption process, the more heat to be dissipated, but the higher capacity.
 - Either extensive internal heat removal or the absorbent must be flowing

Ionic Liquids for CO₂ capture

ILs are nonvolatile salts with low melting points, wide liquid phase operating ranges, and very wide range of reaction tunability.



- Potential advantages
 - Good thermal and oxidative stability
 - No evaporation into cleaned gas stream
 - One to one molar reactivity
- Potential disadvantages
 - High molar mass
 - Even our "best #" ILs are more viscous than is ideal
- #Aprotic Heterocyclic Anion (AHA) ILs offer solutions to these issues (Gurkan *et al.* 2010)




Previous effort from our group

“Molten” PCIL (phase change ionic liquid) flowing in a 10 cm tray column used for CO₂ absorption

For the process, the molten IL would have been a slurry.

In principle, this process could work but the “slurry” would be scary

There is a narrow temperature window for the viscosity of the liquid PCIL to, using a slurry would shrink this substantially.




Challenge for any new process:


- In the CO₂ concentration range for flue gas, **aqueous amines** are the best commercial process
 - 10,000's of sailors are kept alive on submarines
 - 1000's of tons/hr of H₂ is produced using amine scrubbing.
- In terms of our process criteria:
 - Temperature is easily controlled even in a large absorber,
 - Continual improvements in capacity with clever chemistry, but still a ways to go.
 - Regeneration temperatures are high enough to allow heat integration with associated processes but the ΔH is large.

Microencapsulation

- Collaboration with Joshua K. Stolaroff of LLNL:
- Encapsulate IL in a polymer coating
- Viscosity of IL is no longer directly a problem



Operate absorber as fluidized bed



Random and structured packing





Absorber: Volumetric efficiency

Diffusion and reaction in capsule

$$\frac{\partial A_b(r, t)}{\partial t} = \frac{\alpha_1}{r^2} \frac{\partial}{\partial r} \left(r^2 \frac{\partial A_b(r, t)}{\partial r} \right) - k_{on} A_b(r, t) A_g(r, t) + k_{off} B(r, t),$$

$$\frac{\partial A_g(r, t)}{\partial t} = \frac{\alpha_2}{r^2} \frac{\partial}{\partial r} \left(r^2 \frac{\partial A_g(r, t)}{\partial r} \right) - k_{on} A_b(r, t) A_g(r, t) + k_{off} B(r, t),$$

$$\frac{\partial B(r, t)}{\partial t} = k_{on} A_b(r, t) A_g(r, t) - k_{off} B(r, t)$$



Amine absorber: $\sim 1 \text{ gmole}/(\text{m}^3 \text{ s})$


For 200 μm capsules: $\sim 1 \text{ gmole}/(\text{m}^3 \text{ s})$

Results from past 2 years

- Several refinements in the polymer to prevent chemical reaction with different ionic liquids
- Static, batch uptake of capsules is reversible and matches what is expected for neat IL
- Capsules can be fluidized in a laboratory scale (~ 2 and ~ 4 in diameter) columns
 - CO_2 absorption and recyclability of capsules commensurate with static, batch absorption—desorption experiments.
- Modeling efforts can predict absorption rates
 - Internal mass transfer control

Laboratory Scale Unit

- Video of capsules in 6 cm column, $V = 12 \text{ cm/s}$



LSU – Mass Transfer Measurements

Total Flow Rate (liters/min.)	Composition (vol % CO ₂)	P _{CO2} (bar)	Temp (C)	Absorption Time (s)	Regeneration Amount (L CO ₂)	(mol CO ₂)	Regen Temp (C)	mol ratio	k (cm/s)
3.3	45.67	0.547	71	1236	0.229	0.0096	114	0.65	1.5E-05
3.3	44.55	0.537	73	433	0.224	0.0094	106	0.64	2.2E-04
3.3	45.93	0.561	78	733	0.23	0.0096	109	0.66	3.1E-05
3.3	44.74	0.533	69	673.5	0.228	0.0095	108	0.65	8.8E-05
3.3	45.22	0.542	71	356	0.243	0.0101	114	0.69	1.0E-04

Recyclability (5 cycles) shows consistent CO₂ capacity of 0.66 +/- 0.02 moles CO₂/mol PCIL

Rate Based Model

- Comparison of measured vs. predicted mass transfer flux in a **fluidized bed of microcapsules** containing NDIL0309


Measured mass transfer flux (mol/(m ² ·s))	Predicted mass transfer flux (mol/(m ² ·s))	True prediction (no adjusted parameters)
4.84×10^{-4}	3.33×10^{-4}	Excellent agreement
		Confidence in model

- Absorption temperature = 70 °C; Capsule diameter = 560 μm;
Exposure time = 100 s

New results

- Recyclability of capsules in the presence of water
- Additional modeling comparisons with mass transfer rates for fluidized capsules
- Preliminary results for effect of NO and SO₂ on CO₂ absorption
- Overall conclusion of optimal heat of absorption.


Task 21: Recyclability and uptake is excellent even with water present



Corrected for physical CO₂ uptake by shell material


Meets CO₂ uptake criterion

CO₂ uptake recyclability of NDIL0230 capsules in the presence of water.




Task 22: Additional comparisons of experimentally measured and predicted CO₂ flux data for NDIL0309 microcapsules in laboratory-scale fluidized bed

- Particle size = 586 microns. Total surface area = 0.774 m². IL content = 65 wt% IL, assuming perfect drying.



	Run 1	Run 2	Run 3	Run 4
Temperature	74.5	77.6	72.7	71.7
Inlet Pressure (bar)	0.41	0.19	0.25	0.26
Inlet CO ₂ (vol%)	13.44	13.49	13.33	13.70
Gas flow (L/min)	34.16	31.33	32.16	32.27



Task22: Operating/Capital Cost



absorber temperature = 293.15 K, absorber pressure = 1 bar, stripper pressure = 1 bar, heat of chemical absorption = -50 kJ/mol, entropy of chemical absorption = -130 J/(mol K), IL viscosity = 100 cP, weight fraction IL in capsule = 0.5, and microcapsule diameter = 200 micron. The IL cost was taken to be \$20/kg and the microcapsule shell material cost \$20/kg.

Task 19: Effect of Contaminants

- The fluidized absorber was used for multiple runs where the CO₂-N₂ mixture was spiked 10 PPM of NO or SO₂
- As would be expected from experiments with “neat” IIs, there was some degradation of absorption performance.



Concluding remarks

- We have shown that polymer-encapsulated ionic liquids and phase change ionic liquids
 - Can be made chemically compatible in the presence of CO₂ and water.
 - That these capsules can be fluidized and used to efficiently absorb CO₂ in on a laboratory scale
 - That the mass transfer resistance is controlled by diffusion within the capsule (the polymers have a higher diffusivity than the ILs)
 - That we can model the absorption process and predict an optimal heat of reaction and an optimal stripper temperature
 - That this combination can be used successfully in the presence of water
- Experiments so far indicate that as with a neat IL, NO and SO₂ compete for reaction sites, and hence reduce absorption performance.
 - Some of the degradation is reversible.

Acknowledgments

- David Lang
- DOE Federal Award No. DE-FE0026465



U.S. DEPARTMENT OF
ENERGY

